

Zemax




OPTI 517 Introduction to OpticStudio 16 SP2
Michael Humphreys, Arizona '09 (Bear Down)

Why OpticStudio

- Combines intuitive user interface with complex physics engine
 - Customizable workspace
 - Dozens of sample files to start your design from
 - Robust documentation including a Getting Started Guide and In-Window Help Files
- 25+ years of proven technology
- New OpticStudio users come up to speed in 66% of the time
- Only software that has both sequential and non-sequential
 - Progress from first order design to toleranced imaging system to stray light analysis all from the same software

Workflow



Key Features



- Analysis
 - Ray, wave and diffraction calculations
 - Interactive charts to better visualize results
 - All data is available in both chart and text form
- Optimization
 - We have an optimization wizard that allows easy optimization of your design
 - User defined constraints
 - Built-in tools for stock lens and material matching
- Tolerancing
 - Help incorporate manufacturing/assembly limits in design
 - Scripts to automate process
 - Ability to run Monte Carlo, save files, and perform external analysis

Key Features (cont)

- Manufacturability
 - Design lockdown: automates final steps for production
 - ISO Element Drawing and export XML data
 - Automatic conversion to non-sequential mode including CAD Integration
- Extensibility
 - Robust programming language that is extremely easy to learn (ZPL)
 - API that allows for 2-way external communication with .NET and COM languages (C++, C#, Matlab, Python, and more)

Keyboard Shortcuts

- All keyboard shortcuts are customizable
- Favorites
 - Ctrl+Z: toggle variable
 - F6: Merit Function Editor
 - Ctrl+Shift+Q: Quick Focus
 - Ctrl+Shift+O: Optimization
 - Insert: new editor (above)
 - Ctrl+Insert: new line (below)



Live Demo


- Optimize a singlet including Default Merit Function
 - Show analysis features including spot diagram, wave/ray fans, wavefront map, and MTF curve
- Show mirrors (negative thickness) and decenter/tilt components (coordinate breaks)
- Look at catalogs including materials and lens catalogs
- Open up first order prescription data and system check
- User Interface Wrap-Up

Top 10 Tips/Tricks (in no particular order)

1. Search Bar: allows you to quickly find any feature in OpticStudio.
2. You can automatically shift to paraxial focus by using a *Marginal Ray Height* solve of 0, 0
3. Increment/Decrement values in a cell by using "+1" or "+-1"
4. Remove pickups by toggle variable twice (Ctrl+Z)
5. Add data markers to XY Plots to better analyze data
6. Set "*Update: None*" to speed up UI (does not update all windows on each keystroke)
7. Customize Quick Access Toolbar
8. Analyze -> Rays & Spots -> Single Ray Trace using [Hx, Hy, Px, Py] to see ray segments at each surface
9. Universal Plots allow for easy visualization of changing variables on Merit Function Operand Values (thickness vs RSRE)
10. ISO Element Drawing gives one-click ability to produce drawing

Where to Find More Help

- Look at example files located in *Zemax/Samples*
- Help Tab in the Ribbon Toolbar



- Knowledgebase with over 400 articles and examples
 - <http://www.zemax.com/os/resources/learn/knowledgebase/>
- Zemax Webinars on YouTube
 - <https://www.youtube.com/user/RadiantZemaxLLC>

Conclusion

- Are there any questions?
- If you have issues or trouble throughout the semester, please contact Professor Sasian: jose@optics.arizona.edu

